

FIG.1

FIG.2

OPERATION TABLE

	CLUTCH			BRAKE				OWC			SOLENOID		
	C-1	C-2	C-3	B-1	B-2	B-3	B-4	F-1	F-2	F-3	SL1	SL2	SR
P											×	○	×
REV			○	(○)			○	○			×	○	×
N											×	○	×
1ST	○						(○)			○	×	○	×
2ND	○				(○)	○		○	○		×	○	×
3RD	○		○	(○)		●		○			×	○	×
4TH	○	○	●			●					×	○	×
5TH		○	○	○		●					×	×	○
N-D SHIFT	x-○				x-○					x-○	○-x	○-x	○
(○) INDICATES ENGINE BRAKING ● INDICATES ENGAGEMENT WITHOUT TORQUE TRANSFER × INDICATES DISENGAGEMENT									○ ON × OFF				




FIG.3